

Protex 

**RELAX,
WE'VE
GOT YOU
COVERED.**



Relax, we've got you covered.

Protex furniture covers are designed specifically to withstand the British weather. Made using a triple-layer waterproof fabric, Protex furniture covers will protect furniture from dirt, rain & snow. Protex furniture covers are sewn using a double-stitched join which is then heat-welded for maximum waterproofing and strength. Protex covers are made with a plethora of accessories, such as airvents for circulation, buckles and drawcords to fasten the cover to your furniture, and belts to improve the fit of the cover.

What makes Protex fabric different?

Protex fabric is manufactured from a 300D polyester material woven with Hexgrid Anti-Rip technology, backed with a breathable TPU membrane. TPU has several advantages compared to PVC, including a cleaner manufacturing process, a higher elasticity and durability, and a much better temperature resistance. Protex fabric has a UV50+ rating, minimising deterioration and damage from the sun over time, as well as a colour-fast rating of 6-7; a best-in-class standard mitigating colour fade from UV damage. Protex fabric has a 3000mm hydrostatic rating, compared to 1000mm PVC backed polyester covers, ensuring a much higher waterproof protection.

What is a hydrostatic rating?

Hydrostatic ratings directly relate to how waterproof a fabric is. The more water that sits on a fabric, the more pressure pushes down, causing water to eventually penetrate the fabric. The higher the hydrostatic rating of a fabric, the more water it can withstand. Light showers require a rating of around 1000mm. Heavy rain and driving wind will create more pressure on the fabric and require a higher rating of around 2000mm.

Advice for best results.

We recommend clearing any "pooling" water that is sitting on your furniture cover. If the cover is used for a prolonged period of time, always ensure proper ventilation. Significant temperature changes between day and night can lead to condensation formation, which is often mistakenly attributed to leakage. Whilst the fabric is breathable, it is not recommended to leave furniture cushions under the cover for extended periods as they may become damp or even wet due to potential condensation. Make sure the furniture is thoroughly dry before using the cover. After fitting the cover to the furniture, use the attached buckles, straps and belts to attach the cover and reduce any excess material from sagging. Ensure the furniture cover is completely dry before storing.

Airvents

Integrated airvents improve ventilation under the furniture cover further minimising moisture buildup. The airvent is shielded from the elements with an additional fabric cover.



Fastening Straps & Buckles

Use the built-in fastening straps & heavy duty plastic buckles to secure the cover to the furniture, avoiding the cover from coming loose in windy conditions.


Side Belts

Protex covers are suitable for a variety of sizes due to the innovative side belts. Use the side belts to tighten the overall fit of the cover to the furniture, reducing excess material from sagging.



Under Belts

On appropriate covers, under belts are also attached to further secure the cover to the furniture. Run the strap under the furniture and clip together using the buckle for maximum security.



Protex

Manufactured for Nova Outdoor Living

