


Aluminium

140*85cm Rectangular Rising Table

SKU: NV016-102-RT-102

2025 v1.0



Assembly Instructions

IMPORTANT NOTICE


This booklet contains useful information about warranty & care instructions. Please keep for future reference.



Parts List


A

x1




B

x2




C

x1




D

x1




E

x4



F

x2



G

x2




Part	Qty	Part Name
A	1	Rising Table Base
B	1	Table Top Frame
C	1	Ceramic Top
D	8	Washer
E	8	M6 x 20mm Screw
F	2	M6 x 30mm Screw
G	1	Allen Key

AFETY ADVICE - READ BEFORE YOU START:

- Ensure that you read this manual before starting to assemble your furniture.
- Never use power drills when assembling the furniture.
- Check that you have all parts from the parts list. Do not throw away any packaging until you are confident that you have all parts.
- Assemble this product on a soft/flat surface.
- Keep any plastic bags, tools, and fittings away from children and pets.
- After prolonged use we recommend you check all the fittings are tightened securely.
- Please do not modify this product, use other tools, or substitute parts to build your item(s), as this will void your warranty.
- Please only use this product for its intended purpose as outdoor furniture within residential environment. Failure to do so will void your warranty.
- Nova Outdoor Living holds no responsibility for any damages caused due to normal wear and tear, incorrect assembly, misuse and/or negligence.
- We reserve the right to make changes for product improvements.
- Please recycle packaging where possible.
- Place the tabletop safely to one side until it is required and never lay the tabletop on hard or rough surfaces during assembly.
- It is recommended that two people lift the tabletop. Ensure you lift with the correct posture & technique.



Step 1

Place the rising table base on a flat, clean surface. Adjust the table base legs to the highest position by pressing the lever as shown below.



Step 2

Loosely secure the rising table base to the table top using the M6 x 20mm screws, washers and an Allen key. Do not tighten any screws at this step.




Step 3

Tightly secure all the M6 x 20mm screws using the Allen key.



ITS TIME!

Now tighten all the screws with the provided Allen key.




Step 4

Secure the lever onto the table top using the M6 x 30mm screws and an Allen key.



Step 5

Turn the table upright onto a flat surface. Carefully place the table top onto the table top frame ensuring the suction rings are flat.



SAFETY WARNING!


Always lift and secure the table top with two people.

IMPORTANT!

Ensure the ceramic faced side is facing upright when positioning onto the table top.


Step 6

To lower, press up on the lever again and push the table top down by applying your weight to the middle of the table top. To raise your table, simply press up on the lever and your table will rise automatically. You can choose the height you like by releasing the lever.



Step 7

Enjoy your new aluminium rising table.



FURNITURE CARE

When moving your furniture, do not drag it across your patio. This can damage the feet of your furniture as well as your patio. Only pick the furniture up by the solid frame.

ALUMINIUM CARE

The aluminium framework is incredibly low maintenance and is resistant to UV rays, salt water, frost and snow and requires only basic care to keep it clean. To clean, simply use a soft cloth that is damp with warm soapy water and wipe down. Allow the furniture to dry in the sun before adding on the cushions and putting your feet up.

Warranty

WARRANTY INFORMATION

We regret to inform you that warranty claims cannot be accepted without proof of purchase. Warranties are valid from the date of delivery to the original purchaser only. For us to help you, please ensure all warranty terms have been adhered to.

These terms can be found at <https://warranty.novaoutdoorliving.co.uk/>

The warranty applies to residential domestic use within the UK only. It does not cover commercial use, misuse, accidental damage, or normal wear and tear. We reserve the right to repair and/or replace parts rather than a complete item at our discretion.

