



3M ROUND ALUMINIUM GARDEN PARASOL


2020 V1.0



IMPORTANT NOTICE

THIS BOOKLET CONTAINS USEFUL INFORMATION
ABOUT WARRANTY & CARE INSTRUCTIONS.
PLEASE KEEP FOR FUTURE REFERENCE.

PARTS LIST



Part	Qty	Part Name
A	1	3m Round Aluminium Garden Parasol - Top Half
B	1	Bottom Pole for Aluminium Garden Parasols

BEFORE YOU START:

- Ensure that you read this manual before starting to assemble your item(s).
- Check that you have all parts from the above part list. Do not throw away any packaging until you are confident that you have all parts.
- Keep all plastic bags and fittings away from small children to avoid danger of suffocation and/or choking.
- Do not modify, use other tools or substitute parts to build your item(s), this can and will void your warranty.
- This product may only be used for its intended purpose as outdoor sun-shade within a residential environment. Failure to do so can and will void your warranty.
- Nova Outdoor Living holds no responsibility for any damages caused due to normal wear and tear, incorrect assembly, mis-use and/or negligence.
- We reserve the right to make changes for product improvements.

SAFETY ADVICE

ASSEMBLY

Located on the bottom pole of the parasol is a push-pin. The bottom pole connects to the top half of the parasol where you will find a hole for the push-pin to come through. **When you first open the canopy it is important to make sure that none of the ribs are crossed.** Use the crank handle on the parasol to put the canopy up and down; turn the crank handle clockwise to put the canopy up and anti-clockwise to put the canopy down. The built-in tilt function can be used when the canopy is up; click in the button and tilt the canopy over to the side until the button pops back out.

Do not over-tighten the crank, this will cause excessive stress on the crank cord which could lead to fraying or snapping.

Do not leave the parasol up when not in use or during windy conditions.

This parasol requires a suitable parasol base. If the parasol is being used through a table, we recommend a 15kg-25kg weighted base. If the parasol is freestanding, we recommend 50kg or heavier.

1 YEAR LIMITED WARRANTY ON ALUMINIUM GARDEN PARASOLS

Garden parasols from Nova are covered by a 1 year limited warranty. This warranty protects you from manufacturing faults / defects. This warranty applies to residential domestic use within the UK only. It does not cover commercial use, mis-use, accidental damage or normal wear and tear. Damaged caused by wind or by over-cranking is not covered under warranty.

Warranty claims cannot be accepted without proof of purchase. Warranties are valid from the date of purchase, to the original purchaser only. For warranty claims to be upheld, all warranty terms must have been adhered to. Guarantee terms can be found at www.warranty.novaoutdoorliving.co.uk

To submit a warranty claim, please submit a Warranty Claim Form with photographic evidence at warranty.novaoutdoorliving.co.uk

COMPONENTS LIST

Code	Part Name
NPT-18-001	Top Screw Cap
NPT-18-002	Bottom Pole for Aluminium Garden Parasols

NOVA

OUTDOOR LIVING

