


Free Standing 4.0M x 2.4M Pergola

SKU: NV029-424-FS

2026 v1.0



Assembly Instructions

IMPORTANT NOTICE


This booklet contains useful information about warranty & care instructions. Please keep for future reference.



Parts List


A

x4




B1

x1



B2

x1




C

x2




D

x25



G

x1




H

x1



Parts List



Parts List

Part	Qty	Carton	Part	Qty	Carton	Part	Qty	Carton
A	4	1	I	4	1	Q	105	1
B1	1	2	J	4	1	R	14	1
B2	1	2	K	50	1	S	29	1
C	2	2	L	1	1	V	1	1
D	13	3	M	52	1	W	16	1
D	12	4	N	4	1	X	1	1
G	1	2	O	26	1	Y	2	1
H	1	2	P	105	1	Z	1	1

Safety Advice - Before you start


- Ensure that you read this manual before starting to assemble your Pergola.
- Check that you have all parts from the parts list. Do not throw away any packaging until you are confident that you have all parts.
- Assemble this product on a soft/flat surface.
- Keep any plastic bags, tools, and fittings away from children and pets.
- After prolonged use we recommend you check all the fittings are tightened securely.
- Please do not modify this product, use other tools, or substitute parts to build your item(s), as this will void your warranty.
- There are heavy parts within this package. Ensure you lift with the correct posture & technique. Get help moving and/or lifting if necessary.
- Do not leave tools unattended during the assembly process.
- Please only use this product for its intended purpose within a residential environment. Failure to do so will void your warranty.
- Nova Outdoor Living holds no responsibility for any damages caused due to normal wear and tear, incorrect assembly, misuse and/or negligence.
- We reserve the right to make changes for product improvements.
- Please recycle packaging where possible.

Warning:

In snow season or in case of snow forecast open up your shutters in vertical position to avoid any damaging of your pergola.

Assembly Instructions

- The ground where the Pergola is built should be solid but with at least a 1-2° decline to allow the rainwater to drain away.
- If the Pergola is built on completely flat surface, the rainwater will not drain away and the Pergola will start leaking.



Uneven



Sloped

- The Pergola should not be assembled directly under trees and powerlines.
- Keep children and pets away from the assembly area until the work is completed.
- Do not assemble the Pergola in windy or wet conditions.

YOU WILL NEED:



Safety
Gloves



Knife



Hammer



Screw
Driver



Pencil



Safety
Hat



SDS Drill or
Hammer Drill



Tape
Measure



Ladder



Spirit Level


Assembly Instructions

The Recommended Louvre Position


The louvres and gearbox location can be placed in your preferred position. However, for optimum use, the louvres should follow the sun. Please use the guide below to position the Pergola in the recommended position according to the sun's rise and set.

Top Tip

Keep the gearbox location as northerly as possible




STEP 1 ×4 times




Assembly

STEP 2




STEP 3




Assembly

STEP 4




STEP 5




Assembly

STEP 6




STEP 7 ×1 time




Assembly

STEP 8




STEP 9




Assembly


STEP 10



STEP 11 ×24 times




STEP 12




Assembly

STEP 13

Rotate the handle to open the louvres until they are in a vertical position.




STEP 14




Assembly

STEP 15
×4 times




STEP 16
×4 times

Drill into ground using drill bit provided. Not suitable for wood, grass or steel ground.



Dimensions



Care & Maintenance

- Debris can be built up inside the gutters of the Pergola, therefore it is important to clean the gutters regularly as this will allow rainwater to flow through the Pergola.
- Never place any objects on top of the Louvres.
- During snowfall and heavy winds, open the Louvres into the vertical position to prevent damage.
- Do not operate the roof mechanism during frosty and icy conditions.
- To clean, simply use a soft cloth that is damp with warm soapy water and wipe down. This material can be left outside all year round.
- Regularly check that the Pergola is firmly fixed to the ground.
- Regularly check that all fixings are secured within the Pergola.

Warranty Information

We regret to inform you that warranty claims cannot be accepted without proof of purchase. Warranties are valid from the date of delivery to the original purchaser only. For us to help you, please ensure all warranty terms have been adhered to.

These terms can be found at <https://warranty.novaoutdoorliving.co.uk/>

The warranty applies to residential domestic use within the UK only. It does not cover commercial use, misuse, accidental damage, or normal wear and tear. We reserve the right to repair and/or replace parts rather than a complete item at our discretion.

