


Zara

140-180*85cm Rectangular Extending Rising Table

SKU: NV016-102-ET-102

2025 v1.0



Assembly Instructions

IMPORTANT NOTICE


This booklet contains useful information about warranty & care instructions. Please keep for future reference.



Parts List


A

x1




B

x1



C


x8



($\Phi 16 \times 8.5 \times 1.5$)

D

x10



(1/4x20)

E

x1



(4mm)

- A – Table Top
- B – Table Leg
- C – Washer
- D – M6*20mm Screw
- E – Allen Key

AFETY ADVICE - READ BEFORE YOU START:


- Ensure that you read this manual before starting to assemble your furniture.
- Never use power drills when assembling the furniture.
- Check that you have all parts from the parts list. Do not throw away any packaging until you are confident that you have all parts.
- Assemble this product on a soft/flat surface.
- Keep any plastic bags, tools, and fittings away from children and pets.
- After prolonged use we recommend you check all the fittings are tightened securely.
- Please do not modify this product, use other tools, or substitute parts to build your item(s), as this will void your warranty.
- Please only use this product for its intended purpose as outdoor furniture within residential environment. Failure to do so will void your warranty.
- Nova Outdoor Living holds no responsibility for any damages caused due to normal wear and tear, incorrect assembly, misuse and/or negligence.
- We reserve the right to make changes for product improvements.
- Please recycle packaging where possible.

Place the tabletop safely to one side until it is required and never lay the tabletop on hard or rough surfaces during assembly.

It is recommended that two people lift the tabletop. Ensure you lift with the correct posture & technique.


Step 1

Text - Place the rising table base (B) on a clean flat surface. Press the lever to rise the table legs up automatically





B

x1





Step 2

Place the tabletop frame on a clean flat surface. Then carefully line up the rising table base to the screw holes.




Step 3

Once all screws are in loosely, you can tighten them all with the Allen key (G).



Step 4

Place the lever into the designated space. Take 2x bolts (M6x20mm) (D) and tighten with the Allen key (G)



D
x10



(1/4x20)

E
x1



(4mm)

Step 5

Abb.1 Lift up





Abb.2 Lift down



Step 6

Abb.3 Extension





Abb.4 Folding



FURNITURE CARE

When moving your furniture, do not drag it across your patio. This can damage the feet of your furniture as well as your patio. Only pick the furniture up by the solid frame.

ALUMINIUM CARE

The aluminium framework is incredibly low maintenance and is resistant to UV rays, salt water, frost and snow and requires only basic care to keep it clean. To clean, simply use a soft cloth that is damp with warm soapy water and wipe down.

Warranty

WARRANTY INFORMATION

We regret to inform you that warranty claims cannot be accepted without proof of purchase. Warranties are valid from the date of delivery to the original purchaser only. For us to help you, please ensure all warranty terms have been adhered to.

These terms can be found at <https://warranty.novaoutdoorliving.co.uk/>

The warranty applies to residential domestic use within the UK only. It does not cover commercial use, misuse, accidental damage, or normal wear and tear. We reserve the right to repair and/or replace parts rather than a complete item at our discretion.

