


Hayden

Lounge Armchair

SKU: NV016-105-MU-101
2025 v1.0



Assembly Instructions


IMPORTANT NOTICE

This booklet contains useful information about warranty & care instructions. Please keep for future reference.



Parts List



- A – Armrest
- B – Chair Frame
- C – Backrest
- D – Washer
- E – M6 x 50mm
- F – Allen Key
- G – Back Cushion
- H – Base Cushion




AFETY ADVICE - READ BEFORE YOU START:

- Ensure that you read this manual before starting to assemble your furniture.
- Never use power drills when assembling the furniture.
- Check that you have all parts from the parts list. Do not throw away any packaging until you are confident that you have all parts.
- Assemble this product on a soft/flat surface.
- Keep any plastic bags, tools, and fittings away from children and pets.
- After prolonged use we recommend you check all the fittings are tightened securely.
- Please do not modify this product, use other tools, or substitute parts to build your item(s), as this will void your warranty.
- Please only use this product for its intended purpose as outdoor furniture within residential environment. Failure to do so will void your warranty.
- Nova Outdoor Living holds no responsibility for any damages caused due to normal wear and tear, incorrect assembly, misuse and/or negligence.
- We reserve the right to make changes for product improvements.
- Please recycle packaging where possible.


Assembly



2



If necessary, adjust
the legs to align the
extensions



Care & Maintenance

FURNITURE CARE

When moving your furniture, do not drag it across your patio. This can damage the feet of your furniture as well as your patio. Only pick the furniture up by the solid frame.

CUSHION CARE

Whilst the cushions are showerproof, it is advised not to leave them out in the rain as this can make them dirty. When the set is not in use, cushions should be stored in a cool, dry place. Do not leave cushions on the furniture if using a garden protective cover.

To avoid any stains on your cushion cases, clean up any spills immediately with a damp cloth. If your cushions start to look dirty or marked, remove the cushion filling and hand-wash the cushion case in warm, soapy water. Do not use bleach.

We all have a favourite seat, so it is important to keep all cushions in rotation to ensure equal usage. Swapping cushions between seats will provide even wear on the two cushions.

FRAME & ROPE CARE

The aluminium framework is incredibly low maintenance and is resistant to UV rays, salt water, frost and snow and requires only basic care to keep it clean. To clean the aluminium frame and rope simply use a soft brush, apply soap and warm water, rinse thoroughly and air dry. Once you have finished, wash off any residue with clean water. Allow the furniture to dry in the sun before adding on the cushions and putting your feet up.

Warranty

WARRANTY INFORMATION

We regret to inform you that warranty claims cannot be accepted without proof of purchase. Warranties are valid from the date of delivery to the original purchaser only. For us to help you, please ensure all warranty terms have been adhered to.

These terms can be found at <https://warranty.novaoutdoorliving.co.uk/>

The warranty applies to residential domestic use within the UK only. It does not cover commercial use, misuse, accidental damage, or normal wear and tear. We reserve the right to repair and/or replace parts rather than a complete item at our discretion.

