

Avery

Dimension

Reclining Lounge Chair : 84 x 73 x 92 cm

Footstool : 62 x 52 x 45 cm


Coffee Table : 60 x 60 x 50 cm

Grande 5pc Reclining Lounging Set
with Square Side Table

SKU:

NV005-102-LN-107-C03-B1, B2 & B3

2025 V 1.0



Assembly Instructions

IMPORTANT NOTICE

This booklet contains useful information about warranty & care instructions. Please keep for future reference.




Parts List & Safety Advice

Safety Advice

Before you start:

- Ensure that you read this manual before starting to assemble your furniture.
- Check that you have all parts from the parts list. Do not throw away any packaging until you are confident that you have all parts.
- Keep any plastic bags, tools and fittings away from children and pets.
- Please do not modify this product, use other tools, or substitute parts to build your item(s), as this will void your warranty.
- Please only use this product for its intended purpose as outdoor furniture within residential environment. Failure to do so will void your warranty.
- We reserve the right to make changes for product improvements.
- Please recycle packaging where possible.
- Nova Outdoor Living holds no responsibility for any damages caused due to normal wear and tear, misuse and/or negligence.

Parts List




Part	Quantity	Part Name
A	2	Avery Reclining Lounge Chair
B	2	Back Cushion
C	2	Base Cushion
D	2	Avery Footstool
E	2	Footstool Cushion
F	1	Avery Coffee Table
G	1	Glass

HOW TO OPERATE THE RECLINING CHAIR

WORKING THE HYDRAULIC


To recline the armchair pull the side handle up and apply pressure to the back rest whilst seated. When in the desired position release the side handle.



HOW TO OPERATE THE RECLINING CHAIR

WORKING THE HYDRAULIC

To reset the Armchair to the original position, remove all pressure from the back rest and pull the side handle up.



Care & Maintenance

RATTAN CARE

- Rattan furniture is so popular due to being very low maintenance. With this being said, it is still strongly encouraged that you look after your chairs with the occasional upkeep.
- At the start of the season, we recommend cleaning the rattan pieces with warm, soapy water. You can use a cloth or a soft-bristle brush with gentle pressure. Once you have finished, wash off any residue with clean water from the garden hose.
- Allow the chair to dry in the sun before adding on the cushions and putting your feet up.
- When moving your chairs, do not drag them across your patio. This can damage the feet as well as your patio. Only pick the rattan up by the solid frame, not by the more flexible rattan areas.
- For optimum rattan protection we recommend a protective cover is used all year round or for the chairs to be stored away when not in use.

CUSHION CARE

- Whilst the cushions are showerproof, it is advised not to leave them out in the rain as this can make them dirty. When the chair is not in use, cushions should be stored in a cool, dry place. Do not leave cushions on the chair if using a garden protective cover.
- To avoid any stains on your cushion cases, clean up any spills immediately with a damp cloth. If your cushions start to look dirty or marked, remove the cushion filling and hand wash the cushion case in warm, soapy water. Do not use bleach.
- We all have a favourite chair, so it is important to keep all cushions in rotation to ensure equal usage. Swapping cushions between chairs will provide even wear on the cushions.

TABLE CARE

- To prolong the life of the tabletop we recommend you always use place mats and coasters when putting glasses and plates onto the glass.
- Keep your table away from external extreme heat sources.
- We recommend you always use heat mats when placing hot objects on the tabletop.
- Be careful not to drop any objects onto the table as this could damage the tabletop.
- The table is fitted with plastic feet for protection. Never drag the table as this will accelerate wear and tear on the feet, which is not covered under warranty.
- We recommend cleaning the table with warm, soapy water. You can use a cloth or a soft-bristle brush with gentle pressure. Never use abrasive cloths or detergents to clean the glass. Once you have finished, wash off any residue with clean water.
- For optimum glass and rattan protection we recommend a protective cover is used all year round.
- We recommend clearing any spills quickly when exposed to direct sunlight. Any clear liquid on the glass will work as a magnifier, the temperature of the sun's rays will increase creating an extremely hot heat source which could damage the rattan. The same applies to leaving a filled drinks glass on the glass tabletop for an extended period.

Warranty Information

We regret to inform you that warranty claims cannot be accepted without proof of purchase. Warranties are valid from the date of delivery to the original purchaser only. For us to help you, please ensure all warranty terms have been adhered to.

These terms can be found at <https://warranty.novaoutdoorliving.co.uk/>

The warranty applies to residential domestic use within the UK only. It does not cover commercial use, misuse, accidental damage, or normal wear and tear. We reserve the right to repair and/or replace parts rather than a complete item at our discretion.

