

NOVA HESTIA HEATER



Heating element with wire at each end fixed with a clamp



Procedures of replacing the element

1. **Remove the end plate** - Locate the end plate on the side opposite the cable box. Using a screwdriver, carefully unscrew and remove the plate.
2. **Detach the black mesh cover** - Gently remove the black mesh section from the heater.
3. **Remove the grill** - Carefully slide the grill out of the unit.
4. **Remove the second mesh cover** - Repeat step 2 to detach the mesh on the other side.
5. **Remove the fixing plates** - At each end of the reflector, straighten the clips and carefully remove the fixing plates from their slots.
6. **Take out the heating element** - Disconnect the clamps at both ends, then carefully lift the element out of the reflector.
7. **Install the new heating element** - Connect the clamps to the new element, ensuring they are securely attached. Place the element back into position.
8. **Clean the element** - Gently wipe the glass surface of the element to remove any fingerprints or marks.
9. **Test the heater** - Turn on the heater briefly to ensure the new element is working correctly.
10. **Reassemble the heater** - Follow the above steps in reverse order to reassemble the unit securely.