


Heidi High Dining Armchair

SKU:NV041-105-029

2025 v1.0



Assembly Instructions

IMPORTANT NOTICE

This booklet contains useful information about warranty & care instructions. Please keep for future reference.



Parts List & Assembly

A

x1



B

x1




C

x6



D

x6




E

x1




F

x1



Parts List

Part	Qty	Part Name	Part	Qty	Part Name
A	1	Chair Frame	D	6	Washer
B	1	Chair Base	E	1	Allen Key
C	6	M6 x 20mm Screw	F	1	Back/Base Cushion



Care & Maintenance & Warranty

CARE & MAINTENANCE

FURNITURE CARE

When moving your furniture, do not drag it across your patio. This can damage the feet of your furniture as well as your patio. Only pick the furniture up by the solid frame.

ALUMINIUM CARE

The aluminium framework is incredibly low maintenance and is resistant to UV rays, salt water, frost and snow and requires only basic care to keep it clean. To clean, simply use a soft cloth that is damp with warm soapy water and wipe down. Allow the furniture to dry in the sun before adding on the cushions and putting your feet up.

POLYWOOD CARE

Only use mild soapy water and a soft, damp cloth to clean the Polywood.

Glass objects amplify the sun's heat affecting the wood appearance. Do not rest any glass items directly on the polywood. Should any spills occur on the wood, wipe down and clean immediately with warm soapy water. Avoid any sharp articles on the polywood finish.

CUSHION CARE

Whilst the cushions are showerproof, it is advised not to leave them out in the rain as this can make them dirty. When the set is not in use, cushions should be stored in a cool, dry place. Do not leave cushions on the furniture if using a garden protective cover.

To avoid any stains on your cushion cases, clean up any spills immediately with a damp cloth. If your cushions start to look dirty or marked, remove the cushion filling and hand-wash the cushion case in warm, soapy water. Do not use bleach.

We all have a favourite seat, so it is important to keep all cushions in rotation to ensure equal usage. Swapping cushions between seats will provide even wear on the two cushions.

WARRANTY INFORMATION

We regret to inform you that warranty claims cannot be accepted without proof of purchase. Warranties are valid from the date of delivery to the original purchaser only. For us to help you, please ensure all warranty terms have been adhered to. These terms can be found at <https://warranty.novaoutdoorliving.co.uk/>

The warranty applies to residential domestic use within the UK only. It does not cover commercial use, misuse, accidental damage, or normal wear and tear. We reserve the right to repair and/or replace parts rather than a complete item at our discretion.

