

Avery

Dimension

3 Seater Left Arm Sofa : 198 x 83 x 92 CM

3 Seater Right Arm Corner Sofa : 215 x 83 x 92 CM

Triple Bench Footstool : 160 x 47 x 47 CM


Double Bench Footstool : 110 x 47 x 47 CM

Grande Left Hand Corner
Sofa Lounge Dining Set

SKU:

NV005-102-LD-101-C03-B1 & B2

2025 V 1.0



Assembly Instructions

IMPORTANT NOTICE

This booklet contains useful information about warranty & care instructions. Please keep for future reference.



Parts List & Safety Advice

Safety Advice


Before you start:

- Ensure that you read this manual before starting to assemble your furniture.
- Check that you have all parts from the parts list. Do not throw away any packaging until you are confident that you have all parts.
- Keep any plastic bags, tools and fittings away from children and pets.
- Please do not modify this product, use other tools, or substitute parts to build your item(s), as this will void your warranty.
- Please only use this product for its intended purpose as outdoor furniture within residential environment. Failure to do so will void your warranty.
- We reserve the right to make changes for product improvements.
- Please recycle packaging where possible.
- Nova Outdoor Living holds no responsibility for any damages caused due to normal wear and tear, misuse and/or negligence.

Parts List

TOP TIP!

Cushions are often found tucked up inside the bottom of the furniture frame.




Part	Quantity	Part Name
A	1	3 Seater Left Arm Sofa
B	1	3 Seater Right Arm Corner Sofa:
C	1	Triple Bench Footstool
D	1	Double Bench Footstool
E	6	Seat cushion
F	1	Seat cushion for Triple Bench Footstool
G	1	Seat cushion for Double Bench Footstool
H	5	Backrest cushion
I	1	Backrest big cushion for Square corner sofa
J	1	Backrest small cushion for Square corner sofa
K	2	Clip

ASSEMBLY INSTRUCTIONS

SECURING THE RATTAN COMPONENTS

Using the sofa clips please connect the corner sofa component with the two right and left sofa components from underneath the frame at the front and backside.



RATTAN CARE

- Rattan furniture is so popular due to being very low maintenance. With this being said, it is still strongly encouraged that you look after your furniture with the occasional upkeep.
- At the start of the season, we recommend cleaning the rattan pieces with warm, soapy water. You can use a cloth or a soft-bristle brush with gentle pressure. Once you have finished, wash off any residue with clean water from the garden hose.
- Allow the furniture to dry in the sun before adding on the cushions and putting your feet up.
- When moving your furniture, do not drag them across your patio. This can damage the feet as well as your patio. Only pick the rattan up by the solid frame, not by the more flexible rattan areas.
- For optimum rattan protection we recommend a protective cover is used all year round or for the furniture to be stored away when not in use.

CUSHION CARE

- Whilst the cushions are showerproof, it is advised not to leave them out in the rain as this can make them dirty. When the furniture is not in use, cushions should be stored in a cool, dry place. Do not leave cushions on the furniture if using a garden protective cover.
- To avoid any stains on your cushion cases, clean up any spills immediately with a damp cloth. If your cushions start to look dirty or marked, remove the cushion filling and hand wash the cushion case in warm, soapy water. Do not use bleach.
- We all have a favourite furniture, so it is important to keep all cushions in rotation to ensure equal usage. Swapping cushions between furniture will provide even wear on the cushions.

Warranty Information

We regret to inform you that warranty claims cannot be accepted without proof of purchase. Warranties are valid from the date of delivery to the original purchaser only. For us to help you, please ensure all warranty terms have been adhered to.

These terms can be found at <https://warranty.novaoutdoorliving.co.uk/>

The warranty applies to residential domestic use within the UK only. It does not cover commercial use, misuse, accidental damage, or normal wear and tear. We reserve the right to repair and/or replace parts rather than a complete item at our discretion.

