


NOVA

OUTDOOR LIVING

CLEAR WINDOW SLIDING DOOR SIDE WALL


SKU: NV029-100-AC-3.0-CSD /
NV029-100-AC-3.6-CSD / NV029-100-AC-4.0-CSD
2024 V1.0



IMPORTANT NOTICE

THIS BOOKLET CONTAINS USEFUL INFORMATION
ABOUT WARRANTY & CARE INSTRUCTIONS.
PLEASE KEEP FOR FUTURE REFERENCE.

PARTS LIST



Part	Qty	Part Name
A	1	Door with Right Latch
B	1	Door with Right Hook
C	1	Door with Left Hook
D	1	Door with Left Latch
E	2	Top Panel
F	2	Side Panel
G	2	Long Bottom Track

Part	Qty	Part Name
H	1	Short Bottom Track
I	5	Screw Cover
J	5	Expansion Plug
K	5	ST4.2 x 38mm
L	2	ST3.9 x 13mm
M	16	ST4.2 x 16mm


SAFETY ADVICE

BEFORE YOU START:

- Ensure that you read this manual before starting to assemble your doors.
- Check that you have all parts from the parts list. Do not throw away any packaging until you are confident that you have all parts.
- Assemble this product on a soft/flat surface.
- Keep any plastic bags, tools, and fittings away from children and pets.
- After prolonged use we recommend you check all the fittings are tightened securely.
- Please do not modify this product, use other tools, or substitute parts to build your item(s), as this will void your warranty.
- There are heavy parts within this package. Ensure you lift with the correct posture & technique. Get help moving and/or lifting if necessary.
- Do not leave tools unattended during the assembly process.
- Please only use this product for its intended purpose within a residential environment. Failure to do so will void your warranty.
- Nova Outdoor Living holds no responsibility for any damages caused due to normal wear and tear, incorrect assembly, misuse and/or negligence.
- We reserve the right to make changes for product improvements.
- Please recycle packaging where possible.

ASSEMBLY


YOU WILL NEED:




Gloves




Knife




Hammer




Tape measure



Safety Hat




Electric Screw Driver




Ladder

STEP 1



ASSEMBLY

STEP 2




IMPORTANT

Ensure the magnetic strip is facing the inside of the pergola

ASSEMBLY

STEP 3



ASSEMBLY

STEP 4




IMPORTANT

Ensure the magnetic strip is facing the inside of the pergola


ASSEMBLY

STEP 5




ASSEMBLY

STEP 6




ASSEMBLY

STEP 7





ASSEMBLY

STEP 8




ASSEMBLY

STEP 9



ASSEMBLY

STEP 10




IMPORTANT

Ensure door A is
placed on the inside
back track

ASSEMBLY

STEP 11




IMPORTANT

Ensure door B is placed on the outside front track

ASSEMBLY

STEP 12




IMPORTANT

Ensure door C is placed on the outside front track


ASSEMBLY

STEP 13



ASSEMBLY

STEP 14




IMPORTANT

Ensure door D is placed on the inside back track



ASSEMBLY

STEP 15









ASSEMBLY

STEP 16





ASSEMBLY

STEP 17





ASSEMBLY

STEP 18



ASSEMBLY

STEP 19



CARE, MAINTENANCE & WARRANTY INFORMATION

Our range of sliding doors are designed for continual outdoor use. The sliding door frame ensures that you can leave it outside all year round.

SLIDING DOOR CARE

The sliding door framework is incredibly low maintenance and is resistant to UV rays, salt water, frost and snow and requires only basic care to keep it clean.

To clean, simply use a soft cloth that is damp with warm soapy water and wipe down. This material can be left outside all year round.

WARRANTY INFORMATION

We regret to inform you that warranty claims cannot be accepted without proof of purchase. Warranties are valid from the date of delivery to the original purchaser only. For us to help you, please ensure all warranty terms have been adhered to.

These terms can be found at <https://warranty.novaoutdoorliving.co.uk/>

The warranty applies to residential domestic use within the UK only. It does not cover commercial use, misuse, accidental damage or normal wear and tear. We reserve the right to repair and/or replace parts rather than a complete item at our discretion.

NOVA

OUTDOOR LIVING

