


1 Summer ø50 x 44cm Round Side Table – Beige

2

SKU: NV065-102-LN-101

2025 v1.0

3



5

Assembly Instructions

4

IMPORTANT NOTICE

This booklet contains useful information about warranty & care instructions. Please keep for future reference.

N O

V A

6


1

Parts List

2


A

x1



B


x4



3


C

x8




D

x8



E

x1



4

Parts List

Part	Qty	Part Name
A	1	Table Top
B	4	Table Leg
C	8	M8/19x2 Washer


Part	Qty	Part Name
D	8	M8 x 50mm
E	1	Allen Key

Before you start:

- Ensure that you read this manual before starting to assemble your furniture.
- Never use power drills when assembling the furniture.
- Check that you have all parts from the parts list. Do not throw away any packaging until you are confident that you have all parts.
- Assemble this product on a soft/flat surface.
- Keep any plastic bags, tools, and fittings away from children and pets.
- After prolonged use we recommend you check all the fittings are tightened securely.
- Please do not modify this product, use other tools, or substitute parts to build your item(s), as this will void your warranty.
- Please only use this product for its intended purpose as outdoor furniture within residential environment. Failure to do so will void your warranty.
- Nova Outdoor Living holds no responsibility for any damages caused due to normal wear and tear, incorrect assembly, misuse and/or negligence.
- We reserve the right to make changes for product improvements.
- Please recycle packaging where possible.
- Place the tabletop safely to one side until it is required and never lay the tabletop on hard or rough surfaces during assembly.
- It is recommended that two people lift the tabletop. Ensure you lift with the correct posture & technique.

Assembly


STEP 1




Top Tip

Utilise the outer cardboard packaging where possible. This will protect your furniture when assembling and prevent damage.

A x1




B x4





C x8



D x8



STEP 2



Care & Maintenance

Table Top Care

Clean spills immediately with a soft cloth and mild soapy water only.

Treat the surface with a cement sealer 1-2 times a year. If the table takes longer to dry after cleaning, it's time for another treatment.

Glass objects amplify the sun's heat affecting the table top appearance. Do not rest any glass items directly on the table. Always use a placemat to protect against hot or cold items.

Leg Care

Light scratches will blend naturally into the Oak wash finish adding character. For deep scratches, use a matching wood repair stain, marker, or pencil. Avoid sanding, as it can permanently damage the finish. Consider placing protective surfaces on the bottom of your furniture legs to keep your furniture looking its best.

Please note the following is not covered within the warranty:

- General wear and tear including staining and burns.
- Accidental damage
- Splitting and cracking of the timber, which, as it dries out throughout the year, is part of the natural ageing process.
- Wood knots – this is a natural occurrence of wooden furniture.

We regret to inform you that warranty claims cannot be accepted without proof of purchase. Warranties are valid from the date of delivery to the original purchaser only. For us to help you, please ensure all warranty terms have been adhered to.

These terms can be found at <https://warranty.novaoutdoorliving.co.uk/>

The warranty applies to residential domestic use within the UK only. It does not cover commercial use, misuse, accidental damage, or normal wear and tear. We reserve the right to repair and/or replace parts rather than a complete item at our discretion.

